

1.8m (6ft) Tail Call Lead with RJ12 connector

Part No. **QP805/6G1**



Overview

- A short 1.8m tail call lead c/w pear push and RJ12 connector for use with C-TEC's Quantec-Pro call system.
- Plugs directly into the underside of a Quantec-Pro call point.
- Up to two can be used per Quantec-Pro call point.
- Allows users to remotely generate Standard calls from armchairs, beds, etc.
- Activating the pear push or removing the tail call lead from a call point's remote socket will generate a Standard call.



More Information

Quantec-Pro is C-TEC's next generation addressable call system. It keeps everything that is good about existing Quantec – stable protocol, ease of system set-up, optional Cloud based data monitoring – and enhances it with stylish devices, improved power efficiency, greater programming flexibility and more. The result – a powerful, aesthetically-pleasing call system that is perfect for use across the entire care sector.

Technical Specifications

Compatibility	C-TEC's Quantec-Pro System
Alarm current	Determined by the type of control equipment and number / type of field devices connected to the system.
Indicators	Reassurance LED on host call point will illuminate steady when call push is activated and/or removed.
Controls	Red call button.
Connections	RJ12 connector.
Product dimensions (mm)	26 W x 21 H x 74 D mm (pear push). Lead is 1.8m (6ft) long.



Operating conditions/temperature -5°C to +40°C. Max. relative humidity 95% non-condensing.



T 01942 322744 E sales@c-tec.co.uk
F 01942 829867 W www.c-tec.com



C-TEC, Challenge Way, Martland Park, Wigan, WN5 0LD United Kingdom