

Quantec-Pro Tri-Colour Addressable Overdoor Light c/w Sounder

Part No. **QP906A**



Overview

- An addressable tri-colour overdoor light & sounder designed to increase call indication levels in Quantec-Pro sites.
- Can be programmed to illuminate and sound when certain groups of call points are calling.
- Ideal for providing area indication or 'follow me' lights at the ends of corridors, etc
- Flash and sounder rates change/intensify to reflect the urgency of incoming calls.
- Adjustable volume control.
- Tri-colour LEDs and triangular diffuser make it highly visible from a distance.
- Mounts on a standard UK 25mm single gang flush or surface back box.
- Finished in tough, durable ABS plastic.



More Information

Technical Specifications

Power requirements	Nominal 24V DC (from Quantec Controller/Network)
Quiescent current	Less than 1.5mA.
Alarm current	40mA.
Indicators	Tri-colour (red/green/blue) Alarm LEDs (flash rate & colour sequence changes/intensifies to reflect the urgency of incoming calls).
Controls	Adjust volume; Disable sounder.



Connections	R (Red); G (Green); Net +; Net -
Onboard Sounder	Yes. (Sound sequence changes and intensifies to reflect the urgency of the incoming call).
Onboard Infrared Receiver	No.
Product dimensions (mm)	86 W x 86 H x 48 D mm. Mounts on a UK 25mm single gang back box.
Construction & finish	Plastic.
IP Rating	IP41.
Weight	58g
Operating conditions/temperature	-5°C to +40°C. Max. relative humidity 95% non-condensing.



T 01942 322744 E sales@c-tec.co.uk
F 01942 829867 W www.c-tec.com



C-TEC, Challenge Way, Martland Park, Wigan, WN5 0LD United Kingdom