

The SIFER reader spacer introduces a 10 mm offset between the reader and the installation surface which allows a SIFER reader to be installed on a metallic surface without degrading the read range.

The two mounting holes align with those on the SIFER reader mounting plate and the large cable entry cut-out allows the spacer to be fitted over a reader that is already installed without needing to disconnect and re-terminate the cable.

Compatible with SIFER Readers 994720 and 994720MF



Specifications

Physical

Dimensions:	96(h) x 40(w) x 10(d) (mm)
	SIFER Reader + Spacer Depth: 26mm

Compatible Readers

994720 - IR SIFER Smart Card Reader
994720MF - IR SIFER Multi Format Smart Card Reader

Ordering Options

999037

SIFER Reader Spacer
suits SIFER readers manufactured
April 26th 2021 and later



999033

SIFER Reader Spacer
suits SIFER readers manufactured
prior to 26th April 2021

