

Oxi BD

Plug-in, bidirectional receiver with the functions of the Opera system.

The Oxi BD is compatible with all Nice control units with SM connector, so can also be used to make existing Nice automations bidirectional.



Ergonomic design

Antenna connectors, key and programming LED in convenient, practical positions.

Maximum flexibility

Can memorise up to 750 bidirectional transmitters or 1024 unidirectional transmitters. Oxi BD receivers can be used as signal repeaters to increase the operating distance between the transmitters and other Nice bidirectional receivers.

Easy to install

The Oxi BD bidirectional plug-in receiver is designed to simplify installation. Just remove the old unidirectional receiver from the control unit and replace it with the new Oxi BD.

In unidirectional rolling code mode, compatible with previous versions of Nice plug-in and surface mounted receivers.

Technical specification

Reception frequency

433.92 MHz

Transmission frequency

433.92 MHz (BD only)

Input impedance

50 Ohm

Sensitivity

-108 dBm

Decoding

BD, O-Code, FloR, TTS, Flo, Smilo

Number of channels

4 (on "SM" plug-in connector)

Power supply

5 VDC

Absorption

50 mA (max)

Protection class

IP 30

Dimensions/Weight

49.5x18x41.9 h mm / 22 g

Pcs./pack 1



^{*} Transmitter range and receiver reception capacity may be affected by any other devices operating on the same frequency in the area and by the position of the system's radio antenna.