



Product Code

F04813

P.S.U. DIN6

100-240VAC/12VDC-2A

Reference

4813

EAN

8424299048130

Description.

Description

- DIN-6 rail format for easy installation inside an electrical equipment box, or can be screwed directly onto the wall.
- Used to power the different equipment in a Fermax installation.
- Constructed in self-extinguishing VO material.
- Includes a set of covers to protect the connection terminals.

Technical Details

Input frequency: 50-60Hz

It has two operating indicator LEDs:

- LED ON on: indicates that the feeder is in operation.
- OVERLOAD LED on: indicates maximum current exceeded (it will be necessary to reduce the load of the installation or add additional feeder(s)).
- ON+OVERLOAD LED flashing: indicates short circuit.

Details.

Weight (kg)

0.326

Packaging measurements

(height x width x depth) cm

6,5x11,3x9,6

Video Door Entry system

Technologie

GENERICA

Manuals

- 970150 Fuente Alimentacion 12Vdc-2A Ref 4813 V03_26.pdf
- 97048c Fte Alimentacion 12 Vdc-2A Ref 4813 V06_17.pdf

Declaration of conformity

- DOCF04813EN.pdf