

Product Code

F05250

RF BASIC-2B RECEIVER 12-24V



Reference

5250

EAN

8424299052502

Description.

Description

- Autonomous receiver supplied by 12/24Vac/dc that allows to manage up to 500 codes from 868Mhz RF transmitters.
- A channel (emitter pushbutton) can activate one or another relay, or both relays at the same time.
- It allows to opening remotely pedestrian or vehicular doors through a remote control up to 100 metres.
- The receiver also allows a manual programming or via radio programming.
- The receiver includes 2 relays as standard: one configured as monostable and the second relay configured as monostable=impulse or bistable via a jumper (imp/bis) in the same receiver.
- Monostable=impulse activates the relay during 2 seconds per each pulse of the emitter.
- Bistable. Relay is activated and the relay is deactivated per each pulse of the emitter.

Technical Details

- BASIC-2B
- Frequency: 868,35MHz
- Codification: High security changing code
- Memory: 500 codes
- Number of relays: 2 relays
- Power Supply: 12/24Vac/dc $\pm 10\%$
- Relay contacts: 1A
- Consumption in standby / functioning: 60mA / 90mA
- Functional temperature: -20°C to +85°C
- Tightness: IP54 (IP65 with rubber gasket)
- Dimensions: 63x74x25mm
- Box dimensions: 82x190x40mm

Details.

Product measurements (height x width x depth) mm	Weight (kg)	Packaging measurements (height x width x depth) cm	Video Door Entry system Technologie
63x74x25	0.201	4,5x8,4x18,5	NO PE/VP

Access Control Technology

RF

Manuals

- 97853 DOC AXESKEYBASIC_2B_REF. 5250-3200683 V03_22.pdf

Declaration of conformity

- DOCF05250EN.pdf

Accessories



F05231

KEYSINGLE PLUS2 REMOTE CONTROL



F05232

KEYSINGLE PLUS4 REMOTE CONTROL



F04800

P.S.U DIN4 230Vac/12Vac - 1,5A



F04813

P.S.U. DIN6 100-240VAC/12VDC-2A



F05259

RF KEYSINGLE MINI REMOTE
CONTROL